


Quick guide — — Overview buttons and guidance screen



1 North-up or heading-up symbol

This symbol indicates a map view with north-up or heading-up. Touching this symbol changes the map orientation. 17

2 Scale indicator

This figure indicates the map scale. . . . 15

3 “MENU” button

Push this button to display the “Menu” screen. . . vi, vii, 64, 66, 67, 68,70, 81, 118

4 “DEST” button

Push this button to display the “Destination” screen. ix, x, 20, 21

5 “MAP/VOICE” button

Push this button to repeat a voice guidance, cancel one touch scroll, start guidance, and display the current position. 8, 50

6 Zoom out touch-screen button

Touch this button to reduce the map scale. 15

7 “Mark”

Touch this button to register the current position or the cursor position as a memory point. 10

8 “Route”

Touch this button to change the route.
 51, 54

9 “Map View”

Touch this button to browse information about guidance route, to set the Points of Interest to be displayed on the screen, or to record the route. 57, 59, 61, 61

10 “◀◀OFF”

Touch this button to obtain a broader view. Some of the buttons on the screen are not displayed. They are displayed again by touching “ON▶▶”. 84

11 Zoom in touch-screen button

Touch this button to magnify the map scale.
 15

12 Foot print map touch-screen button

Touch this button to display the foot print map and the building information. 15

13 Screen configuration touch-screen button

Touch this button to change the screen mode. 13

14 Distance and time to destination

Displays the distance, the estimated travel time to the destination, and the estimated arrival time at the destination. 50

15 “INFO” button

Push this button to display the “Information” screen. 2, 92, 95, 102, 104

16 “DISPLAY” button

Push this button to display the “Display” screen. 101


17 “GPS” mark (Global Positioning System)

Whenever the vehicle is receiving signals from the GPS, this mark is displayed.
 108

18 Speech command system indicator

The microphone is shown by pushing the speech command switch. The speech command system can be operated while this indicator is shown. 99

— Registering home



1. Push “MENU” button.



2. Touch “My Places”.



3. Touch “Register” of the home.



4. There are 13 different methods to search your home.

See “Destination search” on page 21.



5. Touch “Enter”.

The “Memory Point” screen is displayed.


— Registering preset destinations



6. Touch “OK”.

Registration of home is complete.

You can change the icon, quick access, name, location and phone number. (See “ — Editing memory points” on page 72.)



1. Push “MENU” button.



2. Touch “My Places”.



3. Touch “Register” of the memory points.



4. There are 13 different methods to search preset destinations.

See "Destination search" on page 21.



5. Touch "Enter".


The "Memory Point" screen is displayed.



6. Touch "Quick Access".



7. Touch one of preset buttons 1 to 5.




8. Touch "OK".

Registration of preset destinations is complete.

You can change the icon, quick access, name, location and phone number. (See "Editing memory points" on page 72.)

— Operation flow: guiding the route



1. Push “DEST” button.



2. There are 13 different methods to search destinations.

See “Destination search” on page 21.



3. Touch “Enter”.

The navigation system performs a search for the route.




4. Touch “Guide”, and start driving.

Routes other than the one recommended can also be selected. (See “Starting route guidance” on page 40.)

5. Guidance to the destination is given via voice and on the guidance screen.

— Setting home as the destination



1. Push “DEST” button.




2. Touch

The can be used if your home has been registered. (To register “Home”, see “ — Registering home” on page 76.)



3. Touch “Enter”.

The navigation system performs a search for the route.



4. Touch “Guide”, and start driving.

Routes other than the one recommended can also be selected. (See “Starting route guidance” on page 40.)

5. Guidance to the destination is given via voice and on the guidance screen.